


ELECTRONIC

HELMET (CN-07)


GAME & WATCH



INSERTING THE BATTERIES


Insert two LR43 or SR43 batteries into battery compartment with the positive electrode atop.

When the batteries are exhausted, the display becomes vague and hard to look at, and the sound becomes low or be completely lost. In such a cases, replace the batteries immediately. (This unit may fail if batteries are left exhausted.)



TIME SET

Push ACL switch lightly with a sharp-pointed instrument. Push lightly and do not hold the point down. A display will appear as illustrated.



By pressing Button 1, you will control the hours. Button 2 controls the minutes. When you have set the desired time, press the TIME button and the clock will start. Pattern moves every second.

ALARM SET

Push ALARM switch lightly with a sharp-pointed instrument. Bell mark should appear. (If bell mark does not appear, push again.) Alarm is set when bell mark is on the screen.

PM 12:00

By pressing Button 1 you will control the hours. Button 2 controls the minutes. After setting numbers in above manner, push TIME key to set the time as an alarm time. Check AM/PM of time.



At the alarm time, alarm man appears and swings a bell to chime the time. Alarm sound continues for one minute. Push TIME key to turn off alarm sound. (When GAME & WATCH is in game mode at alarm time, alarm man swings a bell without sound.)

Push TIME key to check the alarm time. It is indicated while the key is depressed.

GAME A

In this game, construction workers try to get from the building on the left to the shed on the right without getting hit by falling tools.

1. Hammers, wrenches and other tools fall from above. Right and left buttons move the worker right and left respectively.
 - * Worker can enter shed only while the door is open.
 - * Once the worker leaves the building on the left he can not return to it.
2. When a worker enters the shed safely, five points are awarded. One point is awarded for every three tools which reach the ground without hitting a worker.
3. When a worker gets hit by a falling tool, a miss is registered.
4. The misses are registered on the upper part of the screen. Three misses and the game ends.
5. While a worker is outside the building, the number of falling tools increases. The number decreases when worker is either in building or enters shed. Falling tools increase in number as game progresses.

6. When player reaches a bonus score (200 or 500 points), any miss marks indicated at the time are erased with a fanfare and game continues.

- * The maximum score indicated is 999 points (Score over 999 points is reset to 0, and game is newly started.)
- * If the unit is left as it is after the game is over, the time display will appear in about five minutes.
- * A game is not interrupted even if TIME key or other game key is depressed during game playing.

GAME B


Differs from GAME A in two ways:

- * As game progresses, tools fall at increasing speed. (In GAME A, speed of falling tool is constant.)
 - * Door of shed remains open for progressively shorter periods of time.
- In all other respects, GAME B is the same as GAME A.

CAUTIONS

1. Do not use pencil or pin when pressing ACL or ALARM switch.
2. As the unit is made of precise electronic components, avoid the use and storage at an extreme temperature or heavy shocks.
3. Especially at low temperatures, the response speed may slow down or the lighting may fail. As the liquid crystal is destroyed at high temperature, never leave the unit in a car which is exposed to direct sun light.
4. As exhausted batteries will give an adverse effect to the unit, replace them without delay. (If the battery is exhausted, the display of the liquid crystal will become vague and difficult to look at.)
5. Be careful not to press the liquid crystal display hoavily. Otherwise, the display may fail.
6. Do not put the unit in the pocket at the back of trousers. The display may be damaged when you take a seat.

7. Wipe any dust with a soft dry cloth.
8. Do not use volatile oils such as thinner or benzine and alcohol for wiping.
9. The liquid crystal may be difficult to look at depending upon the angle. The best angle at which to look is as illustrated in the figure.



SPECIFICATIONS

- Accuracy of the clock : Average daily differential within
 ± 3 secs. (under normal temperature)
- Battery : Two Alkali-Manganese batteries
(LR43 or SR43)
- Life of the battery : For clock display
Approx. 6 months on LR43
Approx. 12 months on SR43
For one-hour-game a day
Approx. 6 months on LR43
- Working temperature : 10°C to 40°C (50°F to 104°F)

Nintendo Co.,Ltd.